

Door Trim Installation

If you purchased the Optional Door Trim Kit, install per the drawing below. Install screws through the trim on the door jamb into the 2 x 4s approximately 6" apart. You should glue the trim on the door edge as there is no wood to screw to. A good quality glue like Gorilla Glue or adhesive caulk works best.

